

AcoustiClip System

Direct to Wall AcoustiClip System

Fitting Guide

www.noisestopsystems.co.uk
info@noisestopsystems.co.uk
01423 339163

NOISE 
SYSTEMS

AcoustiClip Direct Wall System Fitting Guide

Setting out the AcoustiClip

Use the diagram below to determine the best way to space the AcoustiClip and AcoustiChannel furring channels.

Five rows will be sufficient on most walls. Walls over 2.65m will require an additional row of clips and channels.


You can fit the system directly on any solid wall type, including brick, concrete and block.

AcoustiClip Layout Diagram

Maximum spacing horizontally is 1200mm

Maximum spacing vertically is 600mm

AcoustiClips are fixed at the end of each row, 50mm maximum from the adjoining walls



AcoustiClip Direct Wall System Fitting Guide

Step 1.

Ensure any skirting and coving are removed from the wall before installing the solution.

Electrical outlets should be disconnected, and the cable should be lengthened to reinstate once the wall is completed.

Once you have prepared the wall, you can begin fitting your soundproof system.

Step 2.

Fix the AcoustiClips to the wall. Once you have worked out the best layout for your wall, you can start attaching the clips. Don't overtighten the clips; a medium torque on the driver setting should be sufficient. The AcoustiClip will compress approximately 5mm when affixed. SEE THE DIAGRAM FOR POSITIONING THE CLIPS.

Fix the AcoustiClip to the wall using plugs and screws. You will need to pre-drill the hole and use a wall plug and screw to secure the clip. Brown wall plugs would be suitable, and standard screws at least 55mm long.

- Maximum distance between clips is 1200mm
- Maximum distance between furring channels is 600mm
- Maximum distance from the wall and clip is 50mm
- The maximum distance from the floor to the bottom row is 100mm
- The maximum distance from the ceiling to the top row is 150mm

Step 3.

Secure the AcoustiChannel into the AcoustiClip. Pinch the bridge of the furring channel into the teeth of the clip to secure it. To join lengths of AcoustiChannel, overlap them by 100mm and secure them with drywall screws. Avoid overlapping the channel on a clip; join the channels between AcoustiClips.

Step 4.

Fitting the acoustic insulation between the AcoustiChannel: Cut the insulation slabs to fit between the channels, avoiding contact with the channel; it doesn't matter if it contacts the clip.

AcoustiClip Direct Wall System Fitting Guide

Step 5.

Installing the first layer of boards. Using drywall screws, the first layer of acoustic plasterboard is fixed to the AcoustiChannel. Use a minimum screw length of screw of 25mm for this layer. Screws should be every 200mm along the furring channel. Leave a 5mm gap between the bottom edge of the board and the floor, the ceiling, and the return walls. This can be filled with acoustic sealant once this layer is installed. If gaps appear between the boards, use acoustic sealant to fill them.

Step 6.

Installing the final layer of boards. Use 50mm drywall screws to secure the Noisestop 1 Plus Panel. The pre-bonded mass-loaded vinyl membrane on the back of the board will be sandwiched between the two soundboards. Follow the exact fitting instructions for the first layer.

Step 7.


Finishing off your wall. The Acousticlip Systems final layer can be finished in the same way as standard plasterboard. A plaster skim can be applied, or the board's tapered edge can be filled before decorating. You can use lining paper or paint straight onto the boards.

Electrical outlets can be reinstated. We recommend using acoustic putty pads inside the box boxes to maintain the wall's acoustic integrity.

Skirting and coving can be reinstated.

AcoustiClip Direct Wall System Fitting Guide

AcoustiClip Direct System



Cross Section AcoustiClip Direct System

